



FRAMED INTERIOR WALL:

1. A WALL BOARD (1) IS NEEDED FOR THE BASE OF THE APPLICATION SURFACE. (I.E. GYPSUM BOARD, CONCRETE BOARD OR PLYWOOD).
2. INSTALL EXPANDED METAL LATH (2), OVERLAPPING A MINIMUM OF 4 INCHES AND FASTEN WITH GALVANIZED NAILS OR SCREWS AT 6" O.C. VERTICAL AND 16" O.C. HORIZONTAL.
IF USING A CONCRETE BOARD, MOST BUILDING CODES DO NOT REQUIRE THAT METAL LATH OR A SCRATCH COAT BE USED, IF THIS IS THE CASE SKIP THE NEXT TWO STEPS.
4. APPLY A $\frac{1}{2}$ "- $\frac{3}{4}$ " THICK SCRATCH COAT (3) COMPLETELY COVERING THE METAL LATH, THEN USING A METAL SCRAPER OR SMALL SCRAP OF LATH, LIGHTLY RAKE HORIZONTAL GROOVES INTO THE SCRATCH COAT.
5. LET SCRATCH COAT CURE COMPLETELY.
6. LOMBARDIA THIN STONE (4) MAY NOW BE APPLIED USING THE FOLLOWING STEPS:
 - A. COVER THE BACK OF EACH STONE WITH AT LEAST $\frac{1}{2}$ " OF MORTAR
 - B. PRESS STONE FIRMLY INTO PLACE, MAKING EXTRA MORTAR TO OOZE OUT*.
*THIS EXTRA MORTAR MAY BE USED TO CREATE YOUR GROUT JOINTS, IF EXTRA IS NOT USED FOR JOINTS, THE JOINTS CAN BE FILLED WITH GROUT AFTER THE STONE IS INSTALLED USING A GROUT BACK AND/OR A TUCK POINTING TOOL
7. LET STONE SET FOR A LEAST 48 HOURS, THEN CLEAN IN IT'S ENTIRETY WITH A MILD DETERGENT AND A SOFT BRISTLED BRUSH.



MANKATO
Kasota Stone, Inc.

**RECOMMENDED INSTALLATION
FRAMED INTERIOR WALL
LOMBARDIA THIN STONE VENEER**

56

LAST REVISED: 10-24-2007